



- 1 SCREW THE UPRIGHT INTO THE THREADED HOLE IN THE CENTER OF THE BASE. USE THE FACEOUTS OF THE UPRIGHT TO HELP TIGHTEN.